Turnkey USB Link driver installation instructions

Turnkey Software – AirQ, WinSim & Brake for Windows

Please ensure you have the latest version of Turnkey software by visiting our website, links to all the latest downloads can be found on the support page.

Installing the Drivers

Connect the Turnkey USB Link to any free USB Port on your computer and follow the screenshots below depending on your version of Windows. The drivers are available on CD, floppy disk or from our website (please see the support pages).

Windows XP



If downloaded from the website please Browse to the location where you saved the drivers on your computer, otherwise tick the search removable media option and ensure either disc is in the drive.



Select **Continue Anyway** at this point







Windows will now identify the USB serial port option of the Turnkey USB Link, please continue as below.



If downloaded from the website please Browse to the location where you saved the drivers on your computer, otherwise tick the search removable media option and ensure either disc is in the drive.



Select **Continue Anyway** at this point







The computer may now require a reboot as shown below.



Windows 98



If downloaded from the website please Browse to the location where you saved the drivers on your computer, otherwise tick the search removable media option and ensure either disc is in the drive.

Add New Hardware Wizard
Windows will search for new drivers in its driver database on your hard drive, and in any of the following selected locations. Click Next to start the search.
Floppy disk drives
CD-ROM drive
Microsoft Windows Update
Specify a location:
C:\WINDOWS\Desktop\Turnkey USB
Browse...
< Back
Next >
Cancel

Add New Hardware Wizard
Windows driver file search for the device:
Turnkey USB Link
Windows is now ready to install the best driver for this device. Click Back to select a different driver, or click Next to continue.
Location of driver:
C:\WINDOWS\DESKTOP\TURNKE~1\FTDI
< Back
Next >
Cancel

Add New Hardware Wizard
Turnkey USB Link
Windows has finished installing the software that your new hardware device requires.
< Back
Finish
Cancel